


TAILLIGHT

BULB REPLACEMENT

Remove the taillight lens screws.



Replace the taillight bulb.

Make sure that the lens seal rubber is correctly installed, then install the lens and secure it with screws.

