


Riding mode

You can change the riding mode.
The riding mode consists of the following parameters.

P: Engine output level
T: Torque control level
EB: Engine brake level



Riding mode has four modes.
There are four available modes:
SPORT, STANDARD, RAIN and USER.

SPORT, STANDARD and RAIN

- ▶ **SPORT:** This mode is suitable for sports riding. You can feel the highest engine response.
- ▶ **STANDARD:** Standard, all-round mode for a variety of situations.
- ▶ **RAIN:** Good for stable riding on slippery surfaces such as rainy conditions.

These levels cannot be changed.

USER

Each level can be changed.