

# Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

An optional larger tool kit may be available.  
Check with your Honda dealer's parts department.

<b>Importance of Maintenance</b> .....	P. 72	<b>Throttle</b> .....	P. 112
<b>Maintenance Schedule</b> .....	P. 74	<b>Crankcase Breather</b> .....	P. 113
<b>Maintenance Record</b> .....	P. 77	<b>Other Adjustments</b> .....	P. 114
<b>Maintenance Fundamentals</b> .....	P. 78	Adjusting the Headlight Aim .....	P. 114
<b>Removing &amp; Installing Body Components</b> ..	P. 93	Adjusting the Brake Lever .....	P. 115
Battery .....	P. 93	Adjusting the Front Suspension .....	P. 116
Front Seat .....	P. 94	Adjusting the Rear Suspension .....	P. 119
Rear Seat .....	P. 95		
<b>Engine Oil</b> .....	P. 96		
<b>Coolant</b> .....	P. 100		
<b>Brakes</b> .....	P. 102		
<b>Side Stand</b> .....	P. 105		
<b>Drive Chain</b> .....	P. 106		
<b>Clutch</b> .....	P. 109		