

## Engine

Number .....	151
Oil.....	84, 96
Oil Filter .....	98
Overheats .....	123
Starting .....	65
Stop Switch.....	55, 65, 142
Stopping .....	142
Will Not Start .....	122

<b>Environment</b> .....	150
--------------------------	-----

## Equipment

Document Bag.....	70
Helmet Holder .....	69
Owner's Manual .....	70, 142
Tool Kit.....	69

## F

<b>Flooded Engine</b> .....	65
-----------------------------	----

<b>Front Seat</b> .....	94
-------------------------	----

<b>Front Suspension</b> .....	116
-------------------------------	-----

## Fuel

Average Fuel Mileage .....	29
Current Fuel Mileage .....	29
Fuel Consumption .....	30

Gauge .....	21
Recommended .....	68
Remaining.....	21
Reserve Fuel Consumption.....	31
Tank Capacity .....	68

<b>Fuses</b> .....	83, 138
--------------------	---------

## G

<b>Gasohol</b> .....	157
----------------------	-----

<b>Gasoline</b> .....	68
-----------------------	----

<b>Gear Position Indicator</b> .....	20
--------------------------------------	----

## H

<b>Hazard Switch</b> .....	54
----------------------------	----

<b>Headlight Aim</b> .....	114
----------------------------	-----

<b>Headlight Dimmer Switch</b> .....	54
--------------------------------------	----

<b>Helmet Holder</b> .....	69
----------------------------	----

<b>High Beam Indicator</b> .....	51
----------------------------------	----

<b>High Coolant Temperature Indicator</b> .....	52, 123
---	---------

<b>Honda Contacts</b> .....	161
-----------------------------	-----

<b>Horn Button</b> .....	54
--------------------------	----