

## Gauges, Indicators & Displays

|   |  |  |
|---|--|--|
| 4 | right multi-function display             | The display includes the following functions:<br><i>Display Check.</i>   |
|   | fuel gauge                               | Shows approximate fuel supply available (page 24 ).  |
|   | odometer                                 | Shows the total miles or kilometers ridden (page 29 ).   |
|   | tripmeter A & B                          | Shows the number of miles or kilometers ridden since you last reset the meter. The tripmeter has two sub modes, ‘A’ and ‘B’. To zero (0) the tripmeter, push and hold the RESET button (page 29 ). |
|   | digital clock                            | Shows hour and minute (page 31 ).  |
| 5 | right turn signal indicator (green)      | Flashes when the right turn signal operates.   |
| 6 | high coolant temperature indicator (red) | Lights when the coolant is over the specified temperature. If the indicator comes on, pull safely to the side of the road. See pages 201 – 202 for instructions and cautions.                      |