

# Storing Your Honda

---

## Removal from Storage

Refer to *Safety Precautions* on page 78 .

1. Uncover and clean your motorcycle.
2. If your motorcycle has been stored for more than four months — change the engine oil (page 106 ).
3. If your motorcycle has been stored for more than two months — ask your dealer to drain and replace the fuel.
4. Charge the battery (page 161 ) as required. Install the battery.
5. Lubricate the drive chain (page 155 ).
6. Perform a pre-ride inspection (page 45 ), then test-ride your motorcycle at low speeds.