

 **High beam indicator**



 **Left turn signal indicator**

 **Right turn signal indicator**

 **Neutral indicator**

Comes on when the transmission is in Neutral.