

# Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

An optional larger tool kit may be available. Check with your Honda dealer’s parts department.

<b>Importance of Maintenance</b> .....	P. 35	<b>Coolant</b> .....	P. 66
<b>Maintenance Schedule</b> .....	P. 37	<b>Brakes</b> .....	P. 68
<b>Maintenance Fundamentals</b> .....	P. 40	<b>Side Stand</b> .....	P. 71
<b>Removing &amp; Installing Body Components</b> ...	P. 54	<b>Drive Chain</b> .....	P. 72
Battery .....	P. 54	<b>Clutch</b> .....	P. 75
Clip .....	P. 55	<b>Throttle</b> .....	P. 76
Front Seat .....	P. 56	<b>Other Adjustments</b> .....	P. 77
Rear Seat .....	P. 57	Clutch and Brake Levers .....	P. 77
Left Side Cover .....	P. 58	Front Suspension .....	P. 78
<b>Engine Oil</b> .....	P. 59	Rear Suspension .....	P. 81
<b>Air Cleaner</b> .....	P. 63	Headlight Aim .....	P. 83
<b>Crankcase Breather</b> .....	P. 65		