

## Inspecting & Changing Air Cleaner Element

Use a new Honda Genuine air cleaner element or equivalent specified for your motorcycle.

### NOTICE

Using the wrong air cleaner element can result in serious damage to the engine.

1. Remove the rear seat and front seat.  
➤ P. 56, 57
2. Remove the left side cover. ➤ P. 58
3. Remove the screw, bolt and air cleaner cover.

