

Speedometer.....	18
Start Button.....	26
Starting the Engine.....	28
Steering Lock.....	27
Stopping Engine	105
Storage	
Compartment	31
Owner's Manual	31
Storing Your Motorcycle	109
Switches.....	26
T	
Tachometer	18
Throttle.....	76
Tires	
Air Pressure.....	50
Puncture	89
Replacing	53, 89
Transporting Your Motorcycle.....	110
Tripmeter.....	18
Troubleshooting	84
Turn Signal Indicators.....	25

V

Vehicle Identification Number	112
-------------------------------------	-----

W

Warning Indicators On or Flashing	87
Warranty Coverage and Service	121
Washing Your Motorcycle	106
Weight Limit.....	15, 126

Wheels

Front Removal	90
Rear Removal	94