

Speedometer

Tachometer

**NOTICE**

Do not operate the engine in the tachometer red zone. Excessive engine speed can adversely affect engine life.


**Tachometer red zone**  
(excessive engine rpm range)

**Clock (12-hour display)**

To set the clock: P.25

**Fuel gauge**

Remaining fuel when only 1st (E) segment starts flashing:  
approximately 0.74 US gal (2.8 liters)



**If the fuel gauge indicator flash sequentially or turned off:** P.91