

<b>Recommended</b>	
Coolant.....	59, 129
Engine Oil .....	56, 129
Fuel.....	44
<b>Refuelling</b> .....	44
<b>Removal</b>	
Battery.....	65
Clip.....	67
Front Seat.....	68
Fuel Tank Cover Assembly .....	69
Fuel Tank Maintenance Position .....	71
Rear Seat.....	73
Shroud.....	74
<b>Repair Kit</b> .....	103
<b>REV Indicator</b> .....	29, 35
<b>Riding Precautions</b> .....	9
<b>S</b>	
<b>Safety Guidelines</b> .....	3
<b>Safety Precautions</b> .....	8
<b>SEL button</b> .....	16
<b>Serial Numbers</b> .....	125
<b>SET button</b> .....	16
<b>Shifting Gears</b> .....	43

<b>Side Stand</b> .....	85
<b>SIDE STAND indicator</b> .....	35
<b>Specifications</b> .....	128
<b>Speedometer</b> .....	17
<b>Start Button</b> .....	38
<b>Starting the Engine</b> .....	41
<b>Steering Lock</b> .....	40
<b>Stopping Engine</b> .....	118
<b>Stopwatch</b> .....	17, 19, 21
<b>Storage</b>	
Equipment .....	45
Owner's Manual.....	118
Tool Kit.....	46
<b>Storing</b> .....	122
<b>Switches</b> .....	38
<b>T</b>	
<b>Tachometer</b> .....	16
<b>Tachometer Display</b> .....	33
<b>Throttle</b> .....	93
<b>Tool Kit</b> .....	46, 64
<b>Transporting Your Motorcycle</b> .....	123
<b>Tripmeter</b> .....	17, 19, 118
<b>Troubleshooting</b> .....	97