

Combined ABS Indicator (CBR1000RR ABS)

If the Combined ABS indicator operates in one of the following ways, your brakes will continue to work as a conventional system, but without the Combined ABS function. Reduce your speed and have your motorcycle inspected by your dealer as soon as possible.

- Indicator does not come ON when the ignition switch is in the ON position
- Indicator does not go OFF at speeds above 6 mph (10 km/h)
- Indicator comes ON or starts flashing while riding

The Combined ABS indicator may flash if:

- The front wheel leaves the ground for 1 second or more
- Either brake is applied continuously from 0 mph (0 km/h) to 31 mph (50 km/h)
- You turn the rear wheel while your motorcycle is lifted off the ground

This is normal but the Combined ABS is not in operation. To activate the system again, turn the ignition OFF, then ON again.

HESD (Honda Electronic Steering Damper) Indicator

If the indicator comes ON while riding, you may have a serious problem with the HESD. Reduce speed and have your motorcycle inspected by your dealer as soon as possible.