

Instruments *(Continued)*


Lap Timer

You can display and record lap time, fuel consumption, travel distance, driving time, and average fuel mileage.

Press SEL button and SET button at the same time when the motorcycle is stopped. The ordinary display switches to the lap time mode. **➡ P.33**

Press and hold SEL button when the motorcycle is stopped. The display switches between the lap time mode and lap time recall mode. **➡ P.35**

To return to the ordinary display, press SEL button and SET button at the same time when the motorcycle is stopped.



SEL button press and hold ⇒

SEL button and SET button press ➔