

Environment	122
F	
Flooded Engine	42
Front Brake Lever Adjustment	87
Front Seat	65
Front Suspension	88
Fuel	
Consumption Meter	20
Low Fuel Indicator	37, 39
Mileage Meter.....	20
Oxygenated.....	130
Recommended	44
Remaining	37, 39
Tank Capacity.....	44
Fuses.....	57, 111
G	
Gasohol.....	130
Gasoline	44
H	
Headlight Aim	92
Headlight Dimmer Switch	40
Helmet Holder	45
HESD (Honda Electronic Steering Damper)	117
HESD (Honda Electronic Steering Damper) Indicator	37
High Beam Indicator.....	36
High Coolant Temperature Indicator	36, 95
Honda Contacts	134
Horn Button	40
I	
Ignition Cut-off System	
Banking Sensor	116
Side Stand	78
Ignition Key.....	115
Ignition Switch.....	40, 41, 116
Indicators.....	36
Information Record	140
Instruments	18