

# Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

An optional tool kit may be available. Check with your Honda dealer’s parts department.

<b>Importance of Maintenance</b> .....	P. 47	<b>Drive Chain</b> .....	P. 79
<b>Maintenance Schedule</b> .....	P. 49	<b>Clutch</b> .....	P. 83
<b>Maintenance Fundamentals</b> .....	P. 52	<b>Throttle</b> .....	P. 86
<b>Removing &amp; Installing Body Components</b> ...	P. 65	<b>Other Adjustments</b> .....	P. 87
Front Seat.....	P. 65	Brake Lever .....	P. 87
Rear Seat.....	P. 66	Front Suspension .....	P. 88
Lower Fairing.....	P. 67	Rear Suspension.....	P. 90
Battery .....	P. 68	Headlight Aim.....	P. 92
<b>Engine Oil</b> .....	P. 70	Brake Light Switch .....	P. 92
<b>Coolant</b> .....	P. 74		
<b>Brakes</b> .....	P. 76		
<b>Side Stand</b> .....	P. 78		