


ABS Motor Fuses (CBR1000RR ABS)



The ABS motor fuses are located on the starter magnetic switch.

To replace these fuses, the fuel tank must be removed.

The ABS motor fuses should be inspected by your dealer, unless the owner has proper tools and service data and is mechanically qualified. Refer to an official Honda Service Manual.

NOTICE

If a fuse fails repeatedly, you likely have an electrical problem. Have your motorcycle inspected by your dealer.