











Instruments (Continued)



DOWN LVL

You can select the shift pedal load level for activating the Quick Shifter when downshifting.

- 1 Select the "DOWN LVL" using the **SEL**  (up) or **SEL**  (down) button, and press the **MODE** button.
 - u Press and hold the **SEL**  (up) or **SEL**  (down) button to move the menu quickly.

| 12:34 | | SETTING | 0 mph |
|-----------------------|---|---|-------|
| SPORTS KIT | SUSPENSION M3 | DOWN | |
| EXIT |  | UP LVL | |
| FUNCTION QUICKSHIFTER | | DOWN LVL | |
| LAP TIME | SUSPENSION A1 |  | |
| DISPLAY | SUSPENSION A2 | UP | |

- 2 Select one of the three levels using the **SEL**  (up) or **SEL**  (down) button.
 - u Press and hold the **SEL**  (up) or **SEL**  (down) button to move the menu quickly.
 - u Available setting range: 1 (light operation) to 3 (heavy operation)

| 12:34 | | SETTING | 0 mph |
|-----------------------|---|---|-------|
| SPORTS KIT | SUSPENSION M3 | | |
| EXIT |  | | 1 |
| FUNCTION QUICKSHIFTER | | | 2 |
| LAP TIME | SUSPENSION A1 | | 3 |
| DISPLAY | SUSPENSION A2 |  | |

- 3 Press the **MODE** button. The "DOWN LVL" setting is set, and then the display returns to the upper level hierarchy.