

INFO 3 display

You can select the following:

- CBR Logo
- Shift indicator set value [REV IND NE]
- Throttle grip angle [GRIP ANGLE]
- Battery voltage [VOLTAGE]
- Date [DATE]
- User letter [USER LETTER]
- Blank display

Changing the INFO 3 display

- 1 Select the INFO 3 display. **➔P.27**
- 2 Press the **SEL ▲** (up) or **SEL ▼** (down) button until the desired display is displayed.
- 3 Press the **MODE** button. The INFO 3 display is set, and then the display moves to the riding mode display.

