

Instruments (Continued)

DISPLAY

| To Set the DISPLAY Menu

- ① Select the "DISPLAY" menu on the main menu screen. ➔ P.43
- ② Select the menu by pressing the [SEL] ▲ (up) or [SEL] ▼ (down) button and press the [MODE] button.

To end the setting

Select the  (return) on the menu screen.
The display returns to the "DISPLAY" menu on the main menu screen.

- ➡ Press the [MODE] button
- ➡ Press the [SEL] ▲ (up) button
- ➡ Press the [SEL] ▼ (down) button

"DISPLAY" is selected

