

# Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

An optional larger tool kit may be available.  
Check with your Honda dealer's parts department.

<b>Importance of Maintenance</b> .....	P. 32	<b>Clutch</b> .....	P. 70
<b>Maintenance Schedule</b> .....	P. 34	<b>Throttle</b> .....	P. 73
<b>Maintenance Fundamentals</b> .....	P. 37	<b>Other Adjustments</b> .....	P. 74
<b>Removing &amp; Installing Body Components</b> ..	P. 50	Adjusting the Headlight Aim .....	P. 74
Battery .....	P. 50	Adjusting the Brake Lever .....	P. 74
Clip .....	P. 51	Adjusting the Front Suspension.....	P. 75
Front Seat .....	P. 52	Adjusting the Rear Suspension .....	P. 77
Right Lower Cowl .....	P. 53		
Rear Seat .....	P. 55		
<b>Engine Oil</b> .....	P. 56		
<b>Coolant</b> .....	P. 60		
<b>Brakes</b> .....	P. 62		
<b>Side Stand</b> .....	P. 65		
<b>Drive Chain</b> .....	P. 66		