

Shifting Gears .....	28
Side Stand.....	66
Side Stand Ignition Cut-off System .....	66
Specifications.....	125
Speedometer .....	20
Start Button .....	24, 27
Starting the Engine .....	27
Steering Lock.....	26
Stopping Engine .....	103
<b>Storage</b>	
Equipment .....	30
Owner's Manual .....	30, 104
Tool Kit.....	30
<b>Storing Your Motorcycle .....</b>	<b>109</b>
<b>Switches .....</b>	<b>24</b>
<b>T</b>	
<b>Tachometer .....</b>	<b>18</b>
<b>Throttle.....</b>	<b>74</b>
<b>Tires</b>	
Air Pressure .....	47
Puncture.....	87
Replacing.....	47, 87
<b>Transporting Your Motorcycle .....</b>	<b>110</b>

<b>Tripmeter.....</b>	<b>21, 104</b>
<b>Troubleshooting .....</b>	<b>81</b>
<b>Turn Signal Indicators .....</b>	<b>23</b>

**V**

<b>Vehicle Identification Number .....</b>	<b>112</b>
--	------------

**W**

<b>Warranty Coverage and Service .....</b>	<b>121</b>
<b>Washing Your Motorcycle.....</b>	<b>105</b>
<b>Weight Limit.....</b>	<b>15, 125</b>

**Wheels**

Front Removal .....	88
Rear Removal.....	92