

2 Clock setting:

- 1 Press SEL button until the desired hour is displayed.
 - ▶ Press and hold SEL button to advance the hour quickly.



- 2 Press SET button. The minute digits start flashing.



- 3 Press SEL button until the desired minute is displayed.
 - ▶ Press and hold SEL button to advance the minute quickly.



- 4 Press SET button. The clock is set, and then the display moves to the backlight brightness adjustment.