Storage Equipment

Tool

The 5 mm Hex wrench is stored behind the right side cover.

To remove the 5 mm Hex wrench, loosen the screw with a coin.


Screw



5 mm Hex wrench

The tools are stored on the underside of the seat.

Store the tools and secure them with the rubber strap as shown.



Removing the Seat P.71

Removing the Right Side Cover