

Installation

Install the parts in the reverse order of removal. Always connect the positive ⊕ terminal first. Make sure that bolts and nuts are tight.

Make sure the clock information is correct after the battery is reconnected. ➤ P. 30

For proper handling of the battery, see "Maintenance Fundamentals." ➤ P. 56

"Battery Goes Dead." ➤ P. 111