


Adjusting the Headlight Aim

You can adjust vertical aim of the headlight for proper alignment. Turn the bolt in or out as necessary using the provided Phillips screwdriver.  P. 43

Obey local laws and regulations.

