

<b>Instruments, Controls, &amp; Other</b>	
<b>Features</b> .....	112
<b>L</b>	
<b>Labels</b> .....	7
<b>Load Limits</b> .....	16
<b>Loading Guidelines</b> .....	16
<b>Low Oil Pressure Indicator</b> .....	29, 94
<b>M</b>	
<b>Maintenance</b>	
Fundamentals .....	48
Importance .....	43
Safety .....	44
Schedule .....	45
<b>Maximum Weight Limit</b> .....	16
<b>Modifications</b> .....	15
<b>N</b>	
<b>Neutral Indicator</b> .....	29, 30
<b>O</b>	
<b>Odometer</b> .....	112
<b>Oil</b>	

Engine .....	55, 68
<b>Overheating</b> .....	93
<b>Oxygenated Fuels</b> .....	125
<b>P</b>	
<b>Parking</b> .....	13
<b>Parts Location</b> .....	20
<b>Passing Light Control Switch</b> .....	32
<b>PGM-FI (Programmed Fuel Injection)</b>	
Malfunction Indicator Lamp (MIL) .....	29, 94
<b>Protective Apparel</b> .....	9
<b>R</b>	
<b>Rear Suspension</b> .....	90
<b>Recommended</b>	
Coolant .....	57
Engine Oil .....	55, 68
Fuel .....	38
<b>Refueling</b> .....	38