Ignition switch

Switches the electrical system on/off. Key can be removed when in the OFF position.

ON Turns electrical system on for starting/riding. OFF Turns engine off.