


To reset the tripmeter, average fuel mileage, average speed and elapsed time

To reset tripmeter A, average fuel mileage, average speed and elapsed time (these are based on tripmeter A) together, press and hold the **MODE** button while tripmeter A or odometer and average fuel mileage, average speed, elapsed time is displayed.



Then, the display returns to the last selected indication.