





Switches

CRF1000A/A II

Headlight dimmer/Passing light control switch


-  : High beam
-  : Low beam
-  **PASS** : Flashes the high beam headlight.

Torque Control switch

Torque Control level setting and Torque Control on/off.  P.61

Handle grip heater switch

CRF1000A II

Change the handle grip heater level or turn the handle grip heater on and off.  P.58

Horn button

Turn signal switch

Pressing the switch turns the turn signal off.

