

I Rear Wheel

Removal

1. Support your motorcycle securely and raise the rear wheel off the ground using a maintenance stand or a hoist.
2. **CRF1000D/D II**
Release the parking brake.
3. **CRF1000A/A II**
Cover both sides of the rear wheel and brake caliper with protective tape or cloth.
CRF1000D/D II
Cover both sides of the rear wheel and brake calipers with protective tape or cloth.

