

<b>I</b>	
<b>Ignition Cut-off System</b>	
Banking Sensor.....	162
Side Stand .....	116
<b>Ignition Key</b> .....	160
<b>Ignition Switch</b> .....	49, 51, 58, 59, 161
<b>Indicators</b> .....	44
<b>Information Record</b> .....	186
<b>Instruments</b> .....	24
<b>Instruments, Controls, &amp; Other</b>	
Features .....	161
<b>L</b>	
<b>Labels</b> .....	8
<b>Load Limits</b> .....	19
<b>Loading Guidelines</b> .....	19
<b>Low Oil Pressure Indicator</b> .....	44, 138
<b>M</b>	
<b>Maintenance</b>	
Fundamentals .....	79
Importance .....	74
Safety .....	75
Schedule.....	76
<b>Maximum Weight Limit</b> .....	19
<b>Modifications</b> .....	17
<b>MT MODE</b> .....	29, 63, 65, 66, 68
<b>N</b>	
<b>N-D Switch</b> .....	50
<b>Neutral Indicator</b> .....	45
<b>O</b>	
<b>Odometer</b> .....	27, 36, 161
<b>Off-Road Safety</b> .....	18
<b>Oil</b>	
Engine.....	86, 104
<b>Overheating</b> .....	137
<b>Oxygenated Fuels</b> .....	176
<b>P</b>	
<b>Parking</b> .....	14
<b>Parking Brake</b> .....	55
<b>Parking Brake Indicator</b> .....	45
<b>Parking Brake Lever</b> .....	55
<b>Parts Location</b> .....	20
<b>Passing Light Control Switch</b> .....	48, 50