


Instruments *(Continued)*

To Exit the Setting Menu


To return to the riding information:

Pull backward the  page switch on the left handlebar.


To return to the Home screen:

Pull backward and hold the  page switch on the left handlebar.

To return the previous screen:

Press the  back switch on the left handlebar.

To operate with the touch screen:

Touch the  to be selected on the touch screen.

Also, the setting mode ends when your vehicle speed reaches approximately 4 mph (6 km/h).

