To Delete Connected Device

❶ Select [Bluetooth], and then press the ENT switch.

❷ Select [Phone Pairing] or [Headset Pairing], and then press the ENT switch to enter the setting menu.

❸ Select the paired device, and then press the ENT switch.

❹ Select [Delete Connected Device], and then press the ENT switch.