

Maintenance Schedule

Items	Frequency	Whichever Comes First		Initial Maint.	Regular Maint. Interval				Refer to page:
		⇒	mi	100	600	1,200	1,800	2,400	
			km	150	1,000	2,000	3,000	4,000	
		Note	Month	1	6	12	18	24	
*	Fuel Line				I		I	–	
*	Throttle Operation				I		I	72	
	Air Cleaner	Note 1		C	C	C	C	67	
	Crankcase Breather			I	I	I	I	71	
	Spark Plug			I	I	I	I	78	
*	Valve Clearance			I	I	I	I	–	
	Engine Oil			R	R	R	R	61	
**	Engine Oil Strainer Screen				C		C	–	
**	Engine Oil Centrifugal Filter				C		C	–	
**	Engine Idle Speed			I	I	I	I	77	

* Should be serviced by your dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 160).

** In the interest of safety, we recommend these items be serviced only by your dealer.