

Servicing Your Honda

Service Preparations

Maintenance Component Locations	53
Tools.....	56
Side Cover Removal	57

Service Procedures

Fluids & Filters

Fuel.....	59
Engine Oil	62
Air Cleaner	68
Crankcase Breather	72

Engine

Throttle.....	73
Clutch System	75
Engine Idle Speed	78
Spark Plug	79
Spark Arrester	81

Chassis

Suspension	83
Brakes.....	86
Wheels.....	94
Tires & Tubes	100
Side Stand	104
Drive Chain	105

Electrical

Battery	112
---------------	-----

Appearance Care	117
-----------------------	-----