Crankcase Breather

Refer to Safety Precautions on page 43.

Service more frequently if your motorcycle is ridden in the rain or often at full throttle.

LEFT SIDE



(1) crankcase breather tube

• Drain the deposits into a suitable container by pinching the crankcase breather tube (1).