

Tire Replacement

The tires that came on your CRF were designed to provide a good combination of handling, braking, durability, and comfort across a broad range of riding conditions.

WARNING

Installing improper tires on your motorcycle can affect handling and stability. This can cause a crash in which you can be seriously hurt or killed.

Always use the size and type of tires recommended in this owner's manual.

- Use a replacement tire equivalent to the original.
- Replace the tube any time you replace a tire. The old tube will probably be stretched and, if installed in a new tire, could fail.

CRF150R

Front	AC	70/100 – 17 40M	
		DUNLOP	MX71F
	CM	70/100 – 17 40M	
		BRIDGESTONE	M23
Rear	AC	90/100 – 14 49M	
		DUNLOP	MX71
	CM	90/100 – 14 49M	
		BRIDGESTONE	M22
Tire type		bias – ply, tube	

CRF150RB

Front	AC	70/100 – 19 42M	
		DUNLOP	MX71F
	CM	70/100 – 19 42M	
		BRIDGESTONE	M61
Rear	AC	90/100 – 16 52M	
		DUNLOP	MX71
	CM	90/100 – 16 52M	
		BRIDGESTONE	M58
Tire type		bias – ply, tube	