

G

gap, spark plug52
 gasohol140
 gasoline.....34
 gearing124
 guidelines, suspension adjustment107

H

handlebar inspection.....88
 Honda,
 contacting149
 Rider’s Club151
 service manual.....148
 your dealer.....150

I

identification, vehicle134
 idle speed, engine48
 inspection, pre-ride.....9

L

labels, safety4
 logbook, competition.....141

M

maintenance,
 additional procedures88
 after competition26
 before & after competition26
 between motos & practice26
 component locations28
 general competition.....22
 importance.....18
 safety19
 schedule.....20
 manual, service.....148
 modifications3

O

oil,
 engine36
 fork72
 transmission39
 operating,
 controls5
 instructions11
 operation component locations6
 optional,
 muffler settings.....118
 parts list143
 sprockets.....124
 oxygenated fuels.....140

P

pads, brake.....78
 parts, optional143
 personal fit adjustments126
 pinging, engine34
 plug, spark52
 pre-load, rear suspension.....102
 pre-ride inspection.....9
 protective apparel2

R

rear suspension maintenance.....71
 Rider’s Club Honda.....151
 riding,
 basic operation11
 before.....7
 important safety information.....2
 safety precautions.....19

S

safety,
 a few words aboutSafety Messages
 important information2
 important precautions.....2
 labels4
 maintenance.....19
 riding precautions.....2
 schedule, maintenance.....20
 seat29
 serial numbers134
 service,
 customer148
 manuals151
 spare parts.....145
 spark knock34
 spark plug,
 maintenance.....52
 reading.....122
 specifications135,136
 spring pre-load, rear suspension102
 starting,
 engine13
 troubleshooting.....131
 steering stem inspection88
 stopping engine14
 storage129
 subframe32

(cont’d)