

Index

A

accessories 3
adjustments,
 altitude and temperature 117
 carburetor 110
 chassis 123
 control freeplay 46, 49, 51
 engine idle speed 48
 for competition 93
 gearing 124
 personal fit 126
 suspension, front 94
 suspension, rear 102
 suspension, track conditions 106
 tire selection 125
after competition maintenance 26
air cleaner 43
air pressure,
 front suspension 94
 tires 80
appearance care 90
authorized manuals 148

B

basic operation 11
before riding 7
between motos & practice maintenance 26
brakes,
 fluid level 76
 lever, front adjustment 75
 pad wear 78
 pedal height 75
break-in guidelines 16

C

capacity, fuel 34
carburetor,
 adjustment 110
 circuit functions 112
 components 110
 disassembly/assembly 114
 idle speed 48
 minor adjustments 120
 optional muffler settings 118
care, appearance 90
chain drive 82
chassis adjustments 123
choke knob 13
cleaner, air 43
cleaning, appearance care 90
clutch system, adjustment 49
competition logbook 141
consumer information 147
contacting Honda 149
controls, operating 5
coolant 41
customer service 149
cylinder system 62

D

damping adjustments,
 front 100
 rear 103
dealer, your Honda 150
diagram, wiring 146
drive chain 82

E

engine,
 flooded 13
 idle speed 48
 number 134
 oil 36
 pinging 34
 starting 13
 stop button 14
 stopping 14
 won't start 13
environment, protecting 130

F

filter,
 air 43
 oil 37
flooded engine, starting 13
fork,
 front suspension adjustment 94
 front suspension inspection 70
 oil recommendation 72
front brake lever adjustment 75
front suspension maintenance 70
fuel,
 line 34
 filter 35
 recommendation 34
 refueling 34
 system 34
 oxygenated 140
 tank capacity 34
 valve 13