This section tells you how to fine tune your CRF for maximum competition performance.

Initial suspension adjustments should be performed after a minimum of 2 hour of easy break-in time.

Optional front and rear suspension springs are available in order to tailor your CRF specifically for your weight, riding style and course conditions.

Follow the instructions given in the rear suspension sag setting section of *Rear Suspension Adjustments* to determine if your combined rider and sprung machine weight (rider fully dressed for competition and machine coolant, oil and fuel levels ready for competition) requires an optional stiffer or softer rear spring. The need for either optional rear spring may need to be balanced by installing the optional fork springs of a similar rate.

Engine Mode Select Button	126
Current Mode	
Mode Selection	126
Front Suspension Adjustments	127
Front Suspension Air Pressure	127
Front Suspension Damping	
Fork Springs	
Fork Oil Adjustment	129
Rear Suspension Adjustments	130
Rear Suspension Spring Pre-Load	130
Rear Suspension Damping	
Rear Suspension Race Sag	132
Suspension Adjustments for	
Frack Conditions	134
Suspension Adjustment Guidelines	135
Funing Tips	138
Spark Plug Reading	138
Chassis Adjustments	139
Rear End	139
Fork Height/Angle	139
Wheelbase	139
Gearing	140
Γire Selection for Track Conditions	141
Personal Fit Adjustments	142
Control Positioning	142
Handlebar Position, Width & Shape	142
_	