

Maintenance Schedule

Perform the *Pre-ride Inspection* (page 13) at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean. R: Replace. A: Adjust. L: Lubricate.

ITEMS	FREQUENCY	NOTE	CRF250R	Each race or about 2.5 hours	Every 3 races or about 7.5 hours	Every 6 races or about 15.0 hours	Every 9 races or about 22.5 hours	Every 12 races or about 30.0 hours	Ref. Page
			CRF250RX	Each race or about 3.5 hours	Every 2 races or about 7.5 hours	Every 4 races or about 15.0 hours	Every 6 races or about 22.5 hours	Every 8 races or about 30.0 hours	
FUEL LINE		(NOTE 6)		I				R	44, 54
FUEL PUMP FILTER		(NOTE 6)						R	48 – 52, 58 – 62
THROTTLE OPERATION				I					74
AIR FILTER		(NOTE 1)		C					70
CRANKCASE BREATHER				I					72
SPARK PLUG				I					81
VALVE CLEARANCE/DECOMPRESSOR SYSTEM		(NOTE 4)				I			82 – 92
ENGINE OIL		(NOTE 3) (NOTE 5)		I		R			64
ENGINE OIL FILTER		(NOTE 3)				R			65
ENGINE IDLE SPEED				I					75
PISTON AND PISTON RINGS						R			93
PISTON PIN						R			96
RADIATOR COOLANT		(NOTE 2)		I					68
COOLING SYSTEM				I					69
DRIVE CHAIN				I, L	R				127
DRIVE CHAIN SLIDER				I					127
DRIVE CHAIN ROLLER				I					128
DRIVE SPROCKET				I					129, 130
DRIVEN SPROCKET				I					129, 130
BRAKE FLUID		(NOTE 2)		I					120
BRAKE PADS WEAR				I					122
BRAKE SYSTEM				I					119
CLUTCH SYSTEM		(NOTE 5)		I					76
CONTROL CABLES				I, L					135
EXHAUST PIPE/MUFFLER				I					131
SUSPENSION				I					102, 118
SWINGARM/SHOCK LINKAGE					L				29, 118
FORK OIL		(NOTE 3)					R		105, 106, 112 – 115, 147
NUTS, BOLTS, FASTENERS				I					136, 176 – 178
WHEELS/TIRES				I					123 – 125
STEERING HEAD BEARINGS							I		135
SIDE STAND		(NOTE 7)		I					126

WE RECOMMEND THESE ITEMS BE SERVICED BY REFERRING TO AN OFFICIAL HONDA SERVICE MANUAL.

This maintenance schedule is based upon average riding condition. Machine subjected to severe use require more frequent servicing.

- NOTE:
- Clean after every moto/race for dusty riding condition.
 - Replace every 2 years. Replacement requires mechanical skill.
 - Replace after the first break-in ride.
 - Inspect after the first break-in ride.
 - Replace the engine oil, if the clutch discs and plates are replaced.
 - Replace every year.
 - Only RX type.