

# Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

An optional larger tool kit may be available.  
Check with your Honda dealer's parts department.

<b>Importance of Maintenance</b> .....	P. 36	<b>Side Stand</b> .....	P. 73
<b>Maintenance Schedule</b> .....	P. 38	<b>Drive Chain</b> .....	P. 74
<b>Maintenance Fundamentals</b> .....	P. 41	<b>Wheels</b> .....	P. 79
<b>Removing &amp; Installing Body Components</b> ..	P. 54	<b>Clutch</b> .....	P. 80
Battery .....	P. 54	<b>Throttle</b> .....	P. 83
Seat .....	P. 55	<b>Crankcase Breather</b> .....	P. 84
Side Cover .....	P. 56	<b>Other Adjustments</b> .....	P. 85
Under Cowl .....	P. 57	Adjusting the Headlight Aim .....	P. 85
<b>Spark Plug</b> .....	P. 58		
<b>Spark Arrester</b> .....	P. 61		
<b>Engine Oil</b> .....	P. 63		
<b>Air Cleaner</b> .....	P. 67		
<b>Coolant</b> .....	P. 68		
<b>Brakes</b> .....	P. 70		