Operation Component Locations

clutch lever

engine mode select button

front brake lever

engine stop button

start button

throttle grip

MIL (amber)
Engine mode indicator (blue)
Launch control system
indicator (purple)

fast idle knob
(engine idle speed)

side stand
(CRF250RX)

shift lever

rear brake pedal