

Multi Information Display


On/Off-Opening/Ending Ceremony

The opening/ending ceremony can be turned off.

1. Push the SETUP button to show the CLOCK ADJUST display (page 27).
2. Push the DIM button to show the OPENING/ENDING CEREMONY display.
3. Push the TRIP or INFO button to switch ON/OFF.
4. Push the SETUP button to fix the setting.

When approximately 5 seconds pass without operating a button on the OPENING/ENDING CEREMONY display, the display automatically returns to the previous display.

ceremony display ON



ceremony display OFF

