

Honda SMART Key System

The Honda SMART Key system allows you to operate the vehicle.

The system runs a two-way authentication between the vehicle and the Honda SMART Key to verify it is the registered Honda SMART Key.

The Honda SMART Key system uses low-intensity radio waves. It may affect medical equipment such as a cardiac pacemakers.

Activate or Deactivate the Honda SMART Key System

To Switch the Honda SMART Key System to Activation or Deactivation

Press and hold the ON/OFF button for more than 1 second.

To Check the Honda SMART Key System Status

Press the ON/OFF button for less than 1 second. The LED of the Honda SMART Key will show the status.

When the LED of the Honda SMART Key:

- | | |
|-----------------------------------|---|
| Blinks 3 times:
(activation) | Honda SMART Key system authentication can be performed. |
| Lights briefly:
(deactivation) | Honda SMART Key system authentication can not be performed. |

