

Quick Reference

These symbols are used in Driver Controls section:

SYMBOL	COMPONENT	SEE PAGE
II	START — ignition switch	25
I	ON — ignition switch	25
○	OFF — ignition switch	25
OFF	OFF — headlight switch	26
≡D	HI — headlight switch	26
≡D	LO — headlight switch	26
D, N, R	Drive — Neutral — Reverse — shift lever	27