Seat

Your Honda MUV is equipped with a bench seat that has two seating positions and is designed to carry one driver and one passenger only. The seat bottom has only one position, but the seat-back is adjustable.

The center of the bench seat is not intended as a seating position and is, therefore, not equipped with a seat belt. Do not allow someone to ride there.

Do not sit on the center of the bench seat.

The center is not equipped with a seat belt.

Not wearing a seat belt can result in serious injury or death.

Do not drive with the any cargo on the center of the seat. Cargo on the center of bench seat can interfere with the drivers ability to control the vehicle and can be thrown around and hurt someone during an overturn or a crash.