If Your Engine Quits or Won't Start

SYMPTOM: Engine starts, but runs poorly.	
POSSIBLE CAUSE	WHAT TO DO
high coolant/oil	Check the high coolant/oil
temperature	temperature indicator.
	Refer to If the <i>High Coolant/Oil</i>
	Temperature Indicator Lights,
	page 186.
runs erratically, misfires	See your dealer.
blubbers (rich fuel	See your dealer.
mixture)	
sooty exhaust (rich fuel	See your dealer.
mixture)	
detonates or pings	If applicable, switch to the
under load	recommended octane gasoline
	(page 96) or change your brand
	of gasoline. If the problem
	persists, see your dealer.
afterfires (backfires)	See your dealer.
pre-ignition (runs on	See your dealer.
after ignition switched	
OFF)	

SYMPTOM: Engine starts, but runs poorly or dies when hot.	
POSSIBLE CAUSE	WHAT TO DO
poor or inadequate fuel	See your dealer.
flow due to clogged fuel	(ensure clean fuel supply)
filter	