

- 5 Press the SEL button until the desired day is displayed.
- ▶ Press and hold the SEL button to advance the day fast.



- 6 Press the SET button. The date is set, and the display returns to the ordinary display.

SP Setting Mode

1 Selecting the user setting mode color:

- 1 Select the SP setting mode. P.36
- 2 Press the SEL button. The color is switched.
 - ▶ When the ECO mode is set to on, AQUA and GREEN can not be selected.
 - ▶ When the shift up mode is set to on, AMBER can not be selected.

